



**SCHEMATYK PODŁĄCZENIA RDG260T - 24V DC**

The diagram illustrates the wiring for the RDG260T unit. It shows a 230V AC power source connected to a power supply (Zasilacz 230V / 24V DC). The power supply outputs 24V DC to the RDG260T unit. The RDG260T unit has terminals L1, Q1, G, G0, and Y50. The 24V DC is connected to L1 and G0. The RDG260T unit controls a fan (Wentylator) and a thermal actuator (SEH - siłownik termiczny). The fan is connected to the RDG260T unit via a 0-10V signal. The thermal actuator is connected to the RDG260T unit via a 0-10V signal. The RDG260T unit also has a 'Do następnego zestawu' (to next set) output, which is connected to a 0-10V signal.

Ustawienia DIP SWITCH (tylna strona panelu sterującego):  
Piny **1 i 7** w pozycji **ON**, pozostałe w pozycji OFF

- przytrzymać dwa skrajne przyciski na 5 sekund – do słyszalnego kliknięcia;
- puścić oba przyciski i na 3 sekundy przytrzymać prawy skrajny – do słyszalnego kliknięcia
- na ekranie pojawi się parametr P, co oznacza wejście w tryb parametrów serwisowych
- za pomocą pokrętki odszukać parametr **P01** i nacisnąć prawy przycisk
- pokrętkę zmienić wartość parametru z fabrycznie ustawionego „1” na „0”
- zatwierdzić i wyjść z ustawień fabrycznych

Rekomendowany przekrój przewodów 1mm<sup>2</sup>